
Rinnai

Installation instructions



Rinnai Condensing Flue System (dens)
Infinity Condensing Series Plume Management Kit

These installation instructions should be kept with the appliance for maintenance


Rinnai

Installation instructions Cutting wallterminal to size

1 Cut off nose in indecated position using a fine teethed saw and deburr the edges.



2 Remove remains of nose using a flat screw driver or pliers



3 install the first 90 degrees elbow and install the complete kit as indicated in the drawings on the reverse side of this leaflet. Extend and divert the installtion to the required position. The extensions can be shortened to length using a fine teethed saw. Always deburr the edges as burrs can damage the seals.



Rinnai Condensing Flue System ondensing Infinity Condensing Series Plume Management Kit

These installation instructions should be kept with the appliance for maintenance

